

GAMA SONIC[®]

SOLAR LIGHTING




**DUAL COLOR PREMIER SOLAR
GARDEN LIGHT**

Part #: 239002

US Patent #7172307

Version 1.1

 Please read the instruction manual carefully to obtain the best results from your purchase.

Thank you for your purchase. GAMA SONIC® solar charged lighting eliminates the problems associated with most solar lighting available today.

GAMA SONIC® has been recognized as a worldwide leader in the lighting industry for over 20 years. The company also offers unique multi-purpose rechargeable products that range from party lights to emergency lighting products.

For technical Assistance/Warranty Claims/Replacement Parts
Toll Free Number: +1-800-835-4113 (only within the US),
Email: support@gamasonic.freshdesk.com

visit our website or download the latest version of your instruction manual:
www.gamasonic.com Or www.gamasonic.com/user-guides

Please read the instruction manual carefully to obtain the best results from your purchase.
Tools that are needed but not supplied with the solar garden light are: A screwdriver.


Solar Wall Light Location

1. For optimum light duration throughout the night, it is very important to place your solar light in a spot where it will receive the maximum amount of direct sunlight throughout the day, free from any obstacles and shade.
2. Make sure the solar panel is not affected by any other light source at night, otherwise the light will not turn ON at dusk.

Note: For best results, allow the solar lamp to be charged for two consecutive sunny days in the "ON" position.

What's Inside

Open your package and remove the contents. Check to make sure all pieces are present and accounted for. This box contains two (2) Dual Color Premier Solar Garden Lights.



Contains 2x Lights!

Operation Instructions

Turn the operation switch to the I (Warm White) or II (Bright White) position, and the solar garden light will automatically operate from dusk to dawn at your chosen color temperature.

- I - Warm White
- 0 - OFF
- II - Bright White



Installation Instructions

1. Screw each of the poles (C) and the fixture (B) together tightly.
2. Attach the stake (D) to the unit by twisting it on to the bottom pole.
3. Insert the stake into the ground, make sure you have turned the lamp to the ON position (either I or II mode).



Replacing the Batteries

After several years of use, the batteries may need replacing.

1. Remove the fixture from the pole by twisting it counter clockwise.
2. Remove the 3 screws from the top of the lamp and remove the top from the fixture.
3. Remove the three screws along the perimeter of the silver reflector on the underside of the top.
4. Take the battery out of its secured position and unclip its wire.
5. Clip your new battery in and reinstall the lamp in reverse order.
6. This solar garden light takes a Li-Ion 3.2V/1000 mAh battery pack - item #GS32V10



Replacement batteries are available at
www.gamasonic.com or via our Toll free number: +1-800-835-4113

WARNING: Do not dispose of Li-ion battery in the regular trash, municipal waste stream or by fire as batteries may leak or explode. Do not open, short circuit, or mutilate batteries as injury may occur. Preserve our environment by recycling Ni-Mh batteries or disposing of them in accordance with local, State and federal regulations. Do not mix old and new batteries.

Maintenance

Clean the solar module regularly with a damp towel to guarantee optimum performance of the solar panel. Do not use any type of solvent for cleaning and be careful not to put too much pressure on the module while cleaning.

Trouble Shooting

If your solar charged light does not come on at dusk despite observance of all the instructions, please try the following steps:

1. Make sure that the solar light is not being affected by any other light source.
2. Ensure the solar light is not positioned in the shade during the day.
3. Make sure the switch in the lamp head is in the "ON" position.
4. Check that the batteries are installed correctly.

NOTE: The performance of the solar light will vary with the time of year. It will deliver more light when it has had a full day in the sun rather than a day in overcast weather.



WINTERTIME TIPS: For optimal performance, be sure to remove any snow or debris accumulation from the solar panel. A solar panel free of debris will charge the batteries much more efficiently.

WARNING: Please keep out of reach of children.